



OYE Active Noise Cancelling Wireless Headphones

OVERVIEW

Thank you for purchasing the Oye Active Noise Cancelling Wireless Headphones. Please read these instructions carefully for proper operation and save for future reference.



OPERATION

Turning ON/OFF

Power on: Hold the MFB Button. The LED indicator will flash red/blue.

Power off: Hold the MFB Button. The LED indicator will turn off.

Connecting with Bluetooth

To play audio from a Bluetooth device, you need to pair the device with your headphones.

1. Turn on the headphones. The light blinks red and blue, indicating the headphones are ready to connect with your Bluetooth device.
2. Turn on Bluetooth mode on your device.
3. Select "Santana Oye" to initiate pairing, and the headphones will automatically connect with your Bluetooth device, indicated by a blue light and voice prompt "Connected". Some devices ask you to input the PIN "0000" as the password.

Note: Generally, there is a 5 minute maximum to pair the headphones with your Bluetooth device, otherwise retry steps 1 to 3 to pair again.

USING THE HEADPHONES

Left and right are indicated by L/R on corresponding ear cups.

Answering a Call

When a call is incoming, you will hear a ring tone. Press the MFB button once to accept the call, or answer the call via your mobile phone.

Rejecting a Call

Long press the MFB button to reject the incoming call.

Ending a Call

Press the MFB button once to end the call, or hang up via your mobile phone.

Music Play / Pause

Press the MFB button once to play/pause music.

Volume Adjustment / Skip Track

Short press the Volume(+) or Volume(-) to adjust volume.

Long press the Volume(+) to select next track.

Long press the Volume(-) to select previous track.

Voice Assistant

Double press the MFB button to activate voice assistant.

Active Noise Cancellation On/Off

Press the ANC On/Off button to turn Active Noise Cancellation on/off.

The LED indicator will turn green when the ANC is on.

The green LED indicator will turn off when ANC is off.

IMPORTANT:

Activate your warranty at SantanaSounds.com

CHARGING THE OYE

1. Before charging, make sure the headphones have been switched off.
2. Plug the USB cable into the charging port of headphones; plug the other side of the USB cable into a USB charger or other charging device. Charging will start, and the red light remains illuminated on the headphones.
3. A full charge takes approximately 2 hours, and then the red light will turn on when fully charged.

Warning: You must use the original cable to charge the Bluetooth headphones, otherwise it may damage the headphones. Proper charger voltage must be 5V with a current rated at 1A.

These headphones use a non-detachable built-in rechargeable battery. In order to prevent damage to the headphones, please do not remove the battery.

Note: The voice prompt "Battery Low" will notify you when the headphones need to be recharged.

WIRED MODE

You can use your headphones in Bluetooth or wired mode. When using your headphones in wired mode, the headphones do not use any battery. Simply plug in the included 3.5mm auxiliary cord into the aux input on the bottom of the headphones.

Note: The remote buttons will not work when using wired mode.

Note: The headphones will power off automatically when using wired mode.

Note: Active Noise Cancellation can remain on when using wired mode, but the playtime will be limited to 6-7 hours.

SPECIFICATIONS

Product Name: Oye

Product Type: Headphones

Wireless Range: 33ft

Standby Time: 200 hours

Playtime: 6-7 hours (ANC off); 3-4 hours (ANC on)

Charging Time: 2 hours

Sensitivity(SPL): 112±3dB

Impedance: 32Ω

Rated Input Power: 15mW

ATTENTION

1. Try to avoid prolonged and continuous uses at high volume which can damage your hearing.
2. Do not wear the headphones while driving or cycling.
3. Avoid placing the headphones in prolonged sun exposure, high temperature or dusty and humid environments, which may affect the normal use.
4. Clean your headphones with a soft cloth, moistened only with mild soap and water. Stronger cleaning agents can damage the surface of the unit.

WARRANTY

What is covered: Any defect in materials and workmanship.

For how long: 1 year from date of purchase.

What we will do: If your product is defective and returned within 30 days after the date it was purchased, we will repair it at no charge to you. If returned after 30 days but within 1 year of the date of purchase we will repair it, or, at our option, replace it at no charge to you. If we repair your product, we may use new or reconditioned replacement parts. If we choose to replace your product we may replace it with a new or reconditioned one of the same or similar design. The repair or replacement will be warranted under our standard one year warranty.

Limitations: Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the product is fit for ordinary use), are limited to 1 year from the date of purchase. We will not pay for loss of time, inconvenience, loss of use of your product or property damage caused by your product or its failure to work, or any other incidental or consequential damages including personal injury. Some states do not allow limitations on how long an implied warranty lasts or the exclusion of limitation of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

What we ask you to do: To get warranty service for your product you must provide proof of the date of purchase. Within 30 days of the date it was purchased, return your product to your place of purchase for immediate replacement. After 30 days, but before the end of the 1 year warranty period, you may contact us at SantanaSounds.com to issue a return authorization. We suggest that you retain your original packaging material in the event you need to ship your product. When sending your product include your name, address, phone number, proof of date of purchase, and a description of the operating problem. After repairing or replacing your product we will ship it to your home within four weeks.

What this warranty does not cover: Among other things this warranty does not cover defects resulting from accidents, unauthorized repair, failure to follow directions, misuse, fire, floods, and acts of God. If your protection is not covered by our warranty, contact us at SantanaSounds.com to determine whether we will repair your product and other repair information, including charges. We, at our option, may replace rather than repair your product with a new or reconditioned one of the same or similar design, the repair or replacement will be warranted for one year. This limited warranty is the only one we give on your product, and it sets forth all our responsibilities regarding your product. There are no warranties that extend beyond the description set forth above.

State law rights: This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

FCC/BLUETOOTH STATEMENT

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Santana Sounds, LLC is under license. Other trademarks and trade names are those of their respective owners.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.